

1. Remove the fabric podim wrap from the case and unroll it.
2. Center the fabric podium wrap with the front center of the case.
3. Line up the velcro strips on the case and fabric wrap.
4. Attach tightly around the case so velcro seams line up on the back side.

